


## Wire-Cutter Models, 10WR, 7WR, 5WR



Wire-Cutter

Micro-Adjustment Screw


Knurled Tips

## Curved Jaw Models, 10CR and 7CR



Involute Jaw Curves


## Straight Jaw Models, 10R and 7R



Easy-Release Trigger

## How to use your VISE-GRIP® Locking Pliers

The adjustable double-lever action of your new VISE-GRIP locking pliers can apply *any amount* of pressure you desire. When properly adjusted, the jaws will hold fragile objects without crushing—or clamp on heavier work with tremendous pressure. Just follow the instructions. Experiment by adjusting the jaws and locking onto a nut or bolt. Then get ready to do more jobs—easier—than you can with any other tool.



### As Ratchet or Pliers

Tighten screw so jaws won't quite lock on work with normal hand pressure. Use like pliers.

### As Wire-Cutter

Wire-Cutter Models will cut ordinary wire in one bite. Progressive bites will cut heavy wire or small bolts.




### To Release Jaws

Place one hand around tool as shown. Hook fingers of other hand around screw handle. Push easy-release trigger with thumb.



### To Adjust Jaws

Place jaws loosely around work with lever slightly open. With other hand, turn micro-adjusting screw until jaws touch work. Squeeze lever to lock.



### How to apply Involute Jaw Curve

Adjust jaws for maximum contact on square, hex or round work.




### How to use Knurled Tips

Hold all kinds of small work at the very tip with tremendous non-slip grip.




## Other VISE-GRIP locking hand tools.

### Locking "C" Clamps, 11R and 6R



Two sizes,  
11" standard  
and 6" mini.

### Long-Reach "C" Clamp, 18R



For hard to  
reach jobs.

### Sheet Metal Tool, 8R



Wide Jaws for  
bending, forming  
upholstering.


U-shaped  
jaws for  
visibility.

### Welding Clamp, 9R




Clamps anything  
19" chain can be  
wrapped around.

### Chain Clamp, 20R



## FULL ONE YEAR WARRANTY

All VISE-GRIP® tools, having passed a rigid factory inspection, are guaranteed against defects in materials and workmanship for one year from date of original purchase. Any VISE-GRIP tool that is abused, or used for purposes other than those for which the tool was designed, is excluded from this warranty. This warranty does not extend to consequential damages except where required by law. If a VISE-GRIP tool appears defective, it may be returned postpaid to the factory. If factory inspection determines that the tool is within this warranty, the tool will be repaired or replaced without charge. (Factory recommendation: an occasional drop of oil on all points of wear will insure better operation and prolong the life of the tool.)




VISE-GRIP and the above outline are trademarks of Petersen Mfg. Co., Inc., DeWitt, Nebraska 68341. Phone (402) 683-2315.  
© Copyright 1979, Petersen Mfg. Co., Inc.


Printed in U.S.A.

Form 720-E


## Do hard jobs—easier!




Use as speed wrench.




Super pliers for twisting wire.




Pull headless nails.




Hold small objects for safer grinding.




Emergency lock-on handle.



Get added leverage on screwdriver.



Use as pipewrench.



Remove door hinge pins.



Clamp any work securely.